



MC3300XR SERIES

RFID Mobile Computers



ZEBRA

Integrator Guide Supplement

Copyright

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corporation, registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©2020 Zebra Technologies Corporation and/or its affiliates. All rights reserved.

COPYRIGHTS & TRADEMARKS: For complete copyright and trademark information, go to www.zebra.com/copyright.

WARRANTY: For complete warranty information, go to www.zebra.com/warranty.

END USER LICENSE AGREEMENT: For complete EULA information, go to www.zebra.com/eula.

For Australia Only

For Australia Only. This warranty is given by Zebra Technologies Asia Pacific Pte. Ltd., 71 Robinson Road, #05-02/03, Singapore 068895, Singapore. Our goods come with guarantees that cannot be excluded under the Australia Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Zebra Technologies Corporation Australia's limited warranty above is in addition to any rights and remedies you may have under the Australian Consumer Law. If you have any queries, please call Zebra Technologies Corporation at +65 6858 0722. You may also visit our website: www.zebra.com for the most updated warranty terms.

Terms of Use

- Proprietary Statement

This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries ("Zebra Technologies"). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

- Product Improvements

Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

- Liability Disclaimer

Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

- Limitation of Liability

In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Revision History

Changes to the original manual are listed below:

Change	Date	Description
-01 Rev A	06/2020	Initial release.

Table of Contents

Copyright	2
For Australia Only	2
Terms of Use	2
Revision History	3

About This Guide

Introduction	7
Configurations	7
Chapter Descriptions	10
Notational Conventions	11
Related Documents	11
Service Information	12
Provide Documentation Feedback	12

Getting Started

Introduction	13
RFID Technology Overview	13
RFID Components	14
Tags	14
Antenna	14
Radio Module	14
Features	15
LED Indications	17
Setting Up the MC3300xR	17

Accessories

Introduction	18
MC3300xR Accessories	18
Compatibility	21
Battery Comparison	21
Battery Compatibility	22
1-Slot USB Charge Cradle	22
Charging the MC3300xR Battery	23
Charging an MC3300xR Spare Battery	24
Battery Charging in 1-Slot USB Charge Cradle	24

Table of Contents

Charging Temperature	25
5-Slot Charge Only ShareCradle	25
Charging the MC3300xR Battery	26
Battery Charging in the 5-Slot Charge Only ShareCradle	26
Charging Temperature	26
5-Slot Ethernet ShareCradle	27
Charging the MC3300xR Battery	27
Battery Charging in the 5-Slot Ethernet ShareCradle	28
Charging Temperature	28
Daisy-chaining Ethernet ShareCradles	28
Ethernet Settings	29
Configuring Ethernet Proxy Settings	29
Configuring Ethernet Static IP Address	30
Establishing Ethernet Connection	31
LED Indicators	32
4-Slot ShareCradle with 4-Slot Battery Charger	32
Charging the MC3300xR Battery	33
Charging Spare Batteries	33
Battery Charging in the 4-Slot ShareCradle with 4-Slot Battery Charger	33
Charging Temperature	33
4-Slot Ethernet ShareCradle with 4-Slot Battery Charger	34
Charging the MC3300xR Battery	34
Charging Spare Batteries	35
Battery Charging in the 4-Slot Ethernet ShareCradle with 4-Slot Battery Charger	35
Charging Temperature	35
Daisy-chaining Ethernet Cradles	35
Ethernet Settings	36
Configuring Ethernet Proxy Settings	36
Configuring Ethernet Static IP Address	37
Establishing Ethernet Connection	38
LED Indicators	39
4-Slot Spare Battery Charger	39
Charging Spare Batteries	39
Battery Charging	40
Spare Battery Charging	40
Charging Temperature	40
20-Slot Spare Battery Charger	40
Charging Spare Batteries	41
Battery Charging	41
Spare Battery Charging	41
Charging Temperature	42
USB Charge Cable	43
Connecting the USB Charge Cable to Device	43
Connecting the USB Charge Cable to Host Computer	44
Main Battery Charging	45
Charging the Device	45
Main Battery Charging	45
Disconnecting the USB Charge Cable	46
MC33XX Charge Only Adapter	47
Adapter Installation	47
Charging Temperature	49

MC3300xR Rubber Boot	49
Fabric Holster	50
Belt Strap	50
Shoulder Strap	51
Using the Belt Strap	52
Using the Shoulder Strap	53
Hand Strap	54

Zebra RFID Mobile Application for Android

RFID Manager

Introduction	57
Using the RFID Manager for Android	57
Connection Status	58
Reader Status	58
Client Application Status	59
RFID Regulatory	60
Settings	61
Firmware Update	64
Recovery Mode	66
RFID Manager Log	67
Exporting Log Files	67

StageNow

Introduction	68
Creating Firmware Update Profile using StageNow	68

Import RFID Manager into StageNow

Introduction	73
Creating Firmware Update Profile using StageNow	73

Troubleshooting

Introduction	80
Troubleshooting the MC3300xR	80

Technical Specifications

Introduction	81
MC3300xR Technical Specifications	81

About This Guide

Introduction

The MC3300xR Integrator Guide Supplement provides the unique set up and operating procedures for MC3300xR. This guide is intended as a supplement to the MC33XX Integrator Guide, p/n MN-003136-xx. Procedures common to MC3300 products are addressed in the MC33XX Integrator Guide.



NOTE: Screens and windows pictured in this guide are samples and can differ from actual screens.

Configurations

Table 1 MC3300xR Configurations

Configuration	Description
MC333U-GJ2EG4EU	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 29 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC333U-GJ2EG4IL	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 29 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ISRAEL ONLY
MC333U-GJ2EG4US	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 29 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC333U-GJ3EG4EU	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 38 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC333U-GJ3EG4US	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 38 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC333U-GJ4EA4CN	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, AOSP, 4GB RAM / 32GB ROM, CHINA ONLY

Table 1 MC3300xR Configurations

Configuration	Description
MC333U-GJ4EG4EU	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC333U-GJ4EG4IN	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, INDIA ONLY
MC333U-GJ4EG4JP	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, JAPAN ONLY
MC333U-GJ4EG4US	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC333U-GJ4EG4WR	MC3330XR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, WORLDWIDE (902-928 MHZ EXCL. NA)
MC339U-GE2EG4EU	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 29 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC339U-GE2EG4US	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 29 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC339U-GE3EG4EU	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 38 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC339U-GE3EG4US	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 38 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC339U-GE4EA4CN	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, AOSP, 4GB RAM / 32GB ROM, CHINA ONLY
MC339U-GE4EG4EU	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC339U-GE4EG4IN	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, INDIA ONLY
MC339U-GE4EG4JP	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, JAPAN ONLY
MC339U-GE4EG4US	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS

Table 1 MC3300xR Configurations

Configuration	Description
MC339U-GE4EG4WR	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, WORLDWIDE (902-928 MHZ EXCL. NA)
MC339U-GF2EG4EU	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 29 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC339U-GF2EG4US	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 29 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC339U-GF3EG4EU	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 38 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC339U-GF3EG4US	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 38 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC339U-GF4EA4CN	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, AOSP, 4GB RAM / 32GB ROM, CHINA ONLY
MC339U-GF4EG4EU	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, ETSI BANDS
MC339U-GF4EG4US	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, FCC BANDS
MC339U-GF4EG4WR	MC3390XR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 47 KEY, EXTENDED CAPACITY BATTERY, GMS, 4GB RAM / 32GB ROM, WORLDWIDE (902-928 MHZ EXCL. NA)
MC339U-GF4EG4TH	MC3390xR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 47 KEY, Extended Capacity Battery, GMS, 4GB RAM / 32GB ROM, THAILAND ONLY
MC339U-GF3EG4TH	MC3390xR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 38 KEY, Extended Capacity Battery, GMS, 4GB RAM / 32GB ROM, THAILAND ONLY
MC339U-GE4EG4TH	MC3390xR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4850 EXTENDED RANGE 2D IMAGER, 47 KEY, Extended Capacity Battery, GMS, 4GB RAM / 32GB ROM, THAILAND ONLY
MC333U-GJ4EG4TH	MC3330xR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, Extended Capacity Battery, GMS, 4GB RAM / 32GB ROM, THAILAND ONLY

Table 1 MC3300xR Configurations

Configuration	Description
MC333U-GJ4EG4SL	MC3330xR UHF RFID GUN, CIRCULAR ANTENNA, 802.11 A/B/G/N/AC, SE4770 2D IMAGER, 47 KEY, Extended Capacity Battery, GMS, 4GB RAM / 32GB ROM, SRI LANKA
MC339U-GF4EG4SL	MC3390xR UHF RFID GUN, LINEAR ANTENNA, 802.11 A/B/G/N/AC, SE4750MR 2D IMAGER, 47 KEY, Extended Capacity Battery, GMS, 4GB RAM / 32GB ROM, SRI LANKA

Chapter Descriptions

Topics covered in this guide are as follows:

- [Getting Started](#) provides information on RFID technology and MC3300xR LED indications.
- [Zebra RFID Mobile Application for Android](#) for Android refers to the new 123RFID Mobile Application.
- [Accessories](#) describes the available accessories and how to use them with MC3300xR.
- [RFID Manager](#) describes how to configure the Zebra RFID Manager Application for MC3300xR.
- [Troubleshooting](#) describes cleaning, maintenance, and troubleshooting procedures.
- [StageNow](#) provides a reference to access this easy Wizard-based tool that allows even complex Staging profiles to become simple to create.
- [Import RFID Manager into StageNow](#) provides instructions necessary to generate an RFID Firmware update profile and import RFID CSP plug-in into the StageNow application.
- [Troubleshooting](#) provides troubleshooting solutions for potential problems during MC3300xR operation.
- [Technical Specifications](#) provides the technical specifications for MC3300xR.

Notational Conventions

The following conventions are used in this document:

- “RFID mobile computer” refers to MC3300xR.
- Bold text is used to highlight the following:
 - Dialog box, window and screen names
 - Drop-down list and list box names
 - Check box and radio button names
 - Icons on a screen
 - Key names on a keypad
 - Button names on a screen.
- Bullets (•) indicate:
 - Action items
 - Lists of alternatives
 - Lists of required steps that are not necessarily sequential
- Sequential lists (e.g., those that describe step-by-step procedures) appear as numbered lists.

Related Documents

The following documents provide more information about the reader.

- MC3330xR Quick Reference Guide, p/n MN-003890-xx.
- MC3390xR Quick Reference Guide, p/n MN-003891-xx.
- Zebra RFID SDK for Android Developer Guide, p/n MN-003158-xx.
- 123RFID Mobile Application User Guide, p/n MN-003765-xx.

For the latest version of this guide and all guides, go to: zebra.com/support.


Service Information

If you have a problem with your equipment, contact Zebra Support Center for your region. Contact information is available at: www.zebra.com/support.

When contacting the Zebra Support Center, please have the following information available:

- Serial number of the unit (found on manufacturing label)
- Model number or product name (found on manufacturing label)
- Software type and version number.

Figure 1 Manufacturing Label



Zebra responds to calls by email or telephone within the time limits set forth in support agreements.

If the problem cannot be solved by the Zebra Support Center, the user may need to return the equipment for servicing and will be given specific directions. Zebra is not responsible for any damages incurred during shipment if the approved shipping container is not used. Shipping the units improperly can possibly void the warranty.

Remove the microSD card from the device before shipping for service.

If you purchased your product from a Zebra business partner, contact that business partner for support.

Provide Documentation Feedback

If you have comments, questions, or suggestions about this guide, send an email to EVM-Techdocs@zebra.com.

Getting Started

Introduction


This chapter provides an overview of RFID technology and components, and describes the MC3300xR LED indications.

RFID Technology Overview

RFID (Radio Frequency Identification) is an advanced automatic identification (Auto ID) technology that uses radio frequency signals to identify tagged items. An RFID tag contains a circuit that can store data. This data may be pre-encoded or can be encoded in the field. The tags come in a variety of shapes and sizes.

To read a tag, the mobile computer sends out radio frequency waves using its integrated antenna. This RF field powers and charges the tags, which are tuned to receive radio waves. The tags use this power to modulate the carrier signal. The reader interprets the modulated signal and converts the data to a format for computer storage. The computer application translates the data into an understandable format.

Figure 2 RFID System Elements



RFID Components

Zebra RFID solutions offer low cost, long read range, and a high read rate. These features provide real time end-to-end visibility of products and assets in the factory, distribution center, retail outlet, or other facility. The MC3300xR's RFID system consists of the following components:

Silicon-based RFID tags that attach to retail products, vehicles, trailers, containers, pallets, boxes, etc.

An integrated antenna that supports applications such as item level tracking and asset tracking.

An embedded radio module that powers and communicates with tags for data capture and provides host connectivity for data migration.

Tags

Tags contain embedded chips that store unique information. Available in various shapes and sizes, tags, often called transponders, receive and respond to data requests. Tags require power to send data.

There are several categories of tags based on the protocol they support, read/write memory, and power options:

Active RFID tags are powered by internal light-weight batteries, and also use these batteries to broadcast radio waves to the reader.

Semi-passive RFID tags are also powered by internal light-weight batteries, but draw broadcasting power from the reader.

Passive RFID tags are powered by a reader-generated RF field. These tags are much lighter and less expensive than active tags, and are typically applied to less expensive goods.

Antenna


Antennas transmit and receive radio frequency signals.

Radio Module

The radio module communicates with the tags and transfers the data to a host computer. It also provides features such as filtering, CRC check, and tag writing. The MC3300xR supports standard RFID tags as described by EPCGlobal™ Class 1 Gen2 protocol.

Features

Figure 3 Parts on the Device - Side View





Item	Description
1	Display - Displays all information needed to operate the MC3330xR.
2	Scan Button - Initiates data capture when a scan application is enabled.
3	NFC Button () - Initiates Near Field Communication (NFC).
4	Keypad - Use to enter data and navigate on screen functions.
5	Power Button - Press and hold to turn on the MC3330xR. Press to turn on or off the screen. Press and hold to select one of these options: Power off - Turn off the device. Reboot - Reboot the device when software stops responding. Airplane mode - Disable all wireless connections. Silent mode - All notifications are disabled except for alarms.
6	Microphone - Use for communications in Handset mode.
7	Hand Strap - Use for securely holding the device.
8	Battery Release Latch - Release the battery from the device.
9	Trigger - Initiates data capture when a scan application is enabled.
10	RFID Module.
11	Charge LED Scan/Decode Status - Indicates the battery charge state while charging or the scan/decode status.

Figure 4 Parts on the Device - Bottom View



Item	Description
1	Battery - Provides power for operating the device.
2	Battery Release Latch - Release the battery from the device.
3	Speaker - Provides audio output for video and music playback.
4	Scanner Exit Window - Provides data capture using the scanner.

LED Indications

The Charge LED Indicator indicates the charge status.

Table 2 LED Charge Indicators

Status	Indications
Off	The battery is not charging. The battery is not inserted correctly in the cradle or connected to a power source. Cradle is not powered.
Green Fast (20 ms)	Tag read and/or write.
Green Slow (200 ms)	Firmware update in progress.
Red (5 s); Green Slow (200 ms)	Firmware recovery mode followed by firmware update.

Setting Up the MC3300xR

To start using the MC3300xR for the first time:

- Ensure the battery is installed
- Charge the MC3300xR
- Power on the MC3300xR
- Remove MC3300xR from charger
- Set the region and power level (using the RFID Manager Application, Demo Application, or the partner application).

Accessories

Introduction

This chapter provides information on using the accessories for the device.

MC3300xR Accessories

The table below lists the accessories available for the MC3300xR.

Table 3 MC3300xR Accessories

Accessory	Part Number	Description
Cradles		
1-Slot USB Charge Cradle with Spare Battery Charger	CRD-MC33-2SUCHG-01	Charges the MC3300xR main battery and a spare battery, and synchronizes the MC3300xR with a host computer through a USB connection. Requires power supply (PWR-BGA12V50W0WW), DC line cord (CBL-DC-388A1-01) and a country specific grounded AC line cord.
5-Slot Charge Only ShareCradle	CRD-MC33-5SCHG-01	Charge only. Charges up to five MC3300xR. Requires power supply (PWR-BGA12V108W0WW), DC line cord (CBL-DC-381A1-01) and a country specific grounded AC line cord.
5-Slot Ethernet ShareCradle	CRD-MC33-5SETH-01	Charges up to five MC3300xR and provides Ethernet communication for up to five devices. Requires power supply (PWR-BGA12V108W0WW), DC line cord (CBL-DC-381A1-01) and a country specific grounded AC line cord.
4-Slot Charge ShareCradle with 4-Slot Battery Charger	CRD-MC33-4SC4BC-01	Charge only. Charges up to four MC3300xR and up to four spare batteries. Requires power supply (PWR-BGA12V108W0WW), DC line cord (CBL-DC-381A1-01) and a country specific grounded AC line cord.

Table 3 MC3300xR Accessories (Continued)

Accessory	Part Number	Description
4-Slot Ethernet ShareCradle with 4-Slot Battery Charger	CRD-MC33-4SE4BC-01	Charges up to four MC3300xR and up to four spare batteries and provides Ethernet communication for up to four MC3300xR. Requires power supply (PWR-BGA12V108W0WW), DC line cord (CBL-DC-381A1-01) and a country specific grounded AC line cord.
Chargers		
4-Slot Spare Battery Charger	SAC-MC33-4SCHG-01	Charges up to four MC3300xR spare batteries. Requires power supply (PWR-BGA12V50W0WW), DC line cord (CBL-DC-388A1-01) and a country specific grounded AC line cord.
20-Slot Spare Battery Charger	SAC-MC33-20SCHG-01	Charges up to 20 MC3300xR spare batteries. Requires power supply (PWR-BGA12V108W0WW), DC line cord (CBL-DC-381A1-01) and a country specific grounded AC line cord.
Power Supply	PWR-BGA12V50W0WW	Level VI power supply. Provides 12 VDC, 2.5A power to the 1-Slot USB Charge Cradle and the 4-Slot Spare Battery Charger. Requires a DC line cord (CBL-DC-388A1-01) and a country specific grounded AC line cord.
Power Supply	PWR-BGA12V108W0WW	Level VI power supply. Provides 12 VDC, 2.5A power to the 5-Slot Charge Only Cradle, 5-Slot Ethernet Cradle, 5-Slot Charge Cradle with 4-Slot Battery Charger, 5-Slot Ethernet Cradle with 4-Slot Battery Charger and 20-Slot Battery Charger. Requires a DC line cord (CBL-DC-381A1-01) and a country specific grounded AC line cord.
Power Supply	PWR-WUA5V12W0US	Wall adapter; Provides 12 VDC, 2.5A power to the USB Charge Cable. Includes plug adapter for use in the United States.
Power Supply	PWR-WUA5V12W0GB	Provides 12 VDC, 2.5A power to the USB Charge Cable. Includes plug adapter for use in the European Union.
Power Supply	PWR-WUA5V12W0EU	Provides 12 VDC, 2.5A power to the USB Charge Cable. Includes plug adapter for use in the United Kingdom.
Power Supply	PWR-WUA5V12W0AU	Provides 12 VDC, 2.5A power to the USB Charge Cable. Includes plug adapter for use in Australia.

Table 3 MC3300xR Accessories (Continued)

Accessory	Part Number	Description
Power Supply	PWR-WUA5V12W0CN	Provides 12 VDC, 2.5A power to the USB Charge Cable. Includes plug adapter for use in China.
Power Supply	PWR-WUA5V12W0IN	Provides 12 VDC, 2.5A power to the USB Charge Cable. Includes plug adapter for use in India.
US AC Line Cord	23844-00-00R	Provides power to 3-wire power supplies PWR-BGA12V50W0WW and PWR-BGA12V108W0WW.
DC Line Cord	CBL-DC-381A1-01	Provides power from the power supply (PWR-BGA12V108W0WW) to the 5-Slot Charge Only Cradle, 5-Slot Ethernet Cradle, 5-Slot Charge Cradle with 4-Slot Battery Charger, 5-Slot Ethernet Cradle with 4-Slot Battery Charger and 20-Slot Battery Charger.
DC Line Cord	CBL-DC-388A1-01	Provides power from the power supply (PWR-BGA12V150W0WW) to the 1-Slot USB Charge Cradle and 4-Slot Battery Charger.
Cables		
USB Charge Cable	CBL-MC33-USBCHG-01	Provides power and/or communication over USB to the device. Requires wall adapter/power supply PWR-WUA5V12W0xx.
1-Slot Cradle USB Cable	25-124330-01R	Provides USB communication through the 1-Slot USB cradle to the host computer.
Miscellaneous		
Cradle Adapter	ADP-MC33-CRDCUP-01	MC3300xR Charge Only Adapter for backwards compatibility with MC32 cradles. Works with MC32N0 1-Slot USB Cradle, 4-Slot Charge Only Cradle, and 4-Slot Ethernet Cradles.
5200 mAh Battery (Extended PowerPrecision+)	BTRY-MC33-52MA-01 BTRY-MC33-52MA-10 BTRY-MC33-52MA-IN	Replacement extended capacity battery. Replacement extended capacity battery (10-pack). Replacement extended capacity battery (India).
Hand Strap	SG-MC33-HDSTPG-01	Replacement hand strap for the MC3300xR. Hand strap loop holds an optional stylus (SG-TC7X-STYLUS-03).
Fabric Holster	SG-MC3021212-01R	Provides a soft, clip on holster and a shoulder strap for the MC3300xR.
Shoulder Strap	58-40000-007R	Universal shoulder strap.

Table 3 MC3300xR Accessories (Continued)

Accessory	Part Number	Description
Belt	11-08062-02R	Belt for fabric holster.
Rubber Boot	SG-MC33-RBTG-02 SG-MC33-RBTG-03	Provides additional protection for wear and tear of the MC3300xR.
Tempered Glass Screen Protector	MISC-MC33-SCRN-01	Provides additional protection for display (5-pack).
Stylus and Tether	SG-TC7X-STYLUS-03	Conductive carbon-filled stylus for capacitive touch panel; includes coiled tether (3-pack).

Compatibility

The table below displays compatibility between MC3300xR and MC32N0 and accessories.

Table 4 Compatibility

	MC3300xR PP+ Batteries	MC32N0 PP Batteries	MC3300xR Cradles	MC32N0 Cradles	MC3300xR Battery Charger	MC32N0 Battery Charger
MC3300xR	Yes	No	Yes	Yes w/adapter	N/A	N/A
MC32N0	No	Yes	No	Yes	N/A	N/A
MC3300xR PP+ Battery	N/A	N/A	Yes	No	Yes	No
MC32N0 PP Battery	N/A	N/A	No	Yes	Yes	Yes

- MC3300xR is compatible with the MC3300xR PowerPrecision+ battery.
- MC3300xR is compatible with all cradles.
An additional adapter is needed to use any MC32N0 cradle slot, which provides charge only, no communication.
- MC3300xR battery charger slots are compatible with all batteries (MC3300xR PowerPrecision+ and MC32N0 PowerPrecision).
- MC32N0 are not compatible with MC3300xR cradles.

Battery Comparison

The table below displays a comparison of the MC3300xR batteries with the MC32N0 batteries.

Table 5 Battery Comparison

Feature	MC32N0	MC3300xR
Battery Type	PowerPrecision	PowerPrecision+
Includes Zebra and PowerPrecision+ recessed logos	No	Yes
Back Label	Grey	Blue

Battery Compatibility


- MC3300xR PowerPrecision+ batteries are compatible with all MC3300xR and accessories.
- MC3300xR PowerPrecision+ batteries are not compatible with MC32N0 and accessories.
- MC32N0 PowerPrecision batteries are compatible with all MC32N0 and accessories.
- MC32N0 PowerPrecision batteries are compatible with all MC3300xR and accessories.

1-Slot USB Charge Cradle

The 1-Slot USB Charge Cradle:

- Provides 9 VDC power for charging the mobile computer and charging the battery.
- Provides 4.2 VDC power to charge the spare battery.
- Provides a USB port for data communication between the mobile computer and a host computer or other USB devices (e.g., a printer).
- Synchronizes information between the mobile computer and a host computer. With customized or third party software, it can also synchronize the mobile computer with corporate databases.
- Compatible with the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries (only in spare battery slot).
 - MC32N0 5200 mAh PowerPrecision extended battery.

Figure 5 1-Slot USB Charge Cradle Setup




Charging the MC3300xR Battery



NOTE: To function properly, remove the lower part of the rubber boot or the entire rubber boot before placing in a charging cradle.

1. Ensure that the cradle is connected to power.
2. Slide the mobile computer into the slot in the cradle. The mobile computer Charge LED Indicator, indicates the mobile computer battery charging status. For charging status, see [Table 6 on page 24](#)

Figure 6 MC3300xR Battery Charging




3. Gently press down on the device to ensure proper contact.
4. When charging is complete, remove the mobile computer from the cradle slot.

Charging an MC3300xR Spare Battery

1. Ensure that the cradle is connected to power.
2. Insert the spare battery into the cradle, bottom first, and pivot the top of the battery down onto the contact pins.

Figure 7 MC3300xR Spare Battery Charging



3. Gently press down on the battery to ensure proper contact.
The Spare Battery Charging LED on the front of the cradle indicates the spare battery charging status.
4. When charging is complete, lift the battery out of the slot.

Battery Charging in 1-Slot USB Charge Cradle

The 1-Slot USB charge cradle charges the MC3300xR's main battery and a spare battery simultaneously.

The MC3300xR's Charge LED indicates the status of the battery charging in the MC3300xR. See [Table 6](#) for charging status indications.

The spare battery charging LED on the cradle indicates the status of the spare battery charging in the cradle. See below for charging status indications.

Table 6 Spare Battery LED Charging Indicators

Spare Battery LED (on cradle)	Indication
Off	<ul style="list-style-type: none"> • The battery is not charging. • The battery is not inserted correctly in the cradle or connected to a power source. • Cradle is not powered.
Solid Amber	<ul style="list-style-type: none"> • Battery is charging.
Solid Green	<ul style="list-style-type: none"> • Battery charging is complete.

Table 6 Spare Battery LED Charging Indicators (Continued)

Spare Battery LED (on cradle)	Indication
Fast Blinking Red 2 blinks/second	Charging error, e.g.: <ul style="list-style-type: none"> Temperature is too low or too high. Charging has gone on too long without completion (typically eight hours).
Solid Red	<ul style="list-style-type: none"> Spare battery is charging and battery is at the end of useful life. Charging complete and battery is at the end of useful life.

The MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries charge from 0% to 90% in less than 3.8 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature


Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.

To accomplish this, for small periods of time, the MC3300xR or cradle alternately enables and disables battery charging to keep the battery at acceptable temperatures. The MC3300xR or cradle indicates when charging is disabled due to abnormal temperatures via its LED.

5-Slot Charge Only ShareCradle

The 5-Slot Charge Only ShareCradle:

- Provides 9 VDC power for operating the mobile computer and charging the battery.
- Simultaneously charges up to five mobile computers.
- Compatible with devices using the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries.

Figure 8 5-Slot Charge Only ShareCradle Setup

Charging the MC3300xR Battery



NOTE: To function properly, remove the lower part of the rubber boot or the entire rubber boot before placing in a charging cradle.

1. Ensure that the cradle is connected to power.
2. Slide the mobile computer into the slot in the cradle. The mobile computer Charge LED Indicator, indicates the mobile computer battery charging status.
3. Gently press down on the device to ensure proper contact.
4. When charging is complete, remove the mobile computer from the cradle slot.

Battery Charging in the 5-Slot Charge Only ShareCradle

The MC3300xR's Charge LED indicates the status of the battery charging in the MC3300xR. See [Table 10 on page 41](#) for charging status indications.

The MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries charges from 0% to 90% in less than 3.8 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature

Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.


To accomplish this, for small periods of time, the MC3300xR or cradle alternately enables and disables battery charging to keep the battery at acceptable temperatures. The MC3300xR or cradle indicates when charging is disabled due to abnormal temperatures via its LED.

5-Slot Ethernet ShareCradle

The 5-Slot Ethernet ShareCradle:

- Provides 9 VDC power for operating the mobile computer and charging the battery.
- Simultaneously charges up to five mobile computers.
- Compatible with devices using the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries.
 - MC32N0 5200 mAh PowerPrecision extended battery.

Figure 9 5-Slot Ethernet ShareCradle Setup



Charging the MC3300xR Battery



NOTE: To function properly, remove the lower part of the rubber boot or the entire rubber boot before placing in a charging cradle.

1. Ensure that the cradle is connected to power.
2. Slide the mobile computer into the slot in the cradle. The mobile computer amber Charge LED Indicator, indicates the mobile computer battery charging status.
3. Gently press down on the device to ensure proper contact.
4. When charging is complete, remove the mobile computer from the cradle slot.

Battery Charging in the 5-Slot Ethernet ShareCradle

The MC3300xR's Charge LED indicates the status of the battery charging in the MC3300xR. See [Table 10 on page 41](#) for charging status indications.

The MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries charges from 0% to 90% in less than 3.8 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature

Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.

To accomplish this, for small periods of time, the MC3300xR or cradle alternately enables and disables battery charging to keep the battery at acceptable temperatures. The MC3300xR or cradle indicates when charging is disabled due to abnormal temperatures via its LED.


Daisy-chaining Ethernet ShareCradles

Daisy-chain up to ten 5-Slot Ethernet ShareCradles to connect several cradles to an Ethernet network. Use either a straight or crossover cable. Daisy-chaining should not be attempted when the main Ethernet connection to the first cradle is 10 Mbps or throughput issues are likely to occur.

To daisy-chain 5-Slot Ethernet ShareCradles:

1. Connect power to each 5-Slot Ethernet ShareCradle.
2. Connect an Ethernet cable to one of the ports on the switch and the other end to the Primary Port of the first cradle.
3. Connect an Ethernet cable to the Secondary port of the first cradle.
4. Connect the other end of the Ethernet cable to the Primary port of the next 5-Slot Ethernet ShareCradle.

Figure 10 Daisy-chaining 5-Slot Ethernet ShareCradles



5. Connect additional cradles as described in step 3 and 4.

Ethernet Settings

The following settings can be configured when using Ethernet communication:

- Proxy Settings
- Static IP.

Configuring Ethernet Proxy Settings

The MC3300xR includes Ethernet cradle drivers. After inserting the MC3300xR, configure the Ethernet connection:



1. Swipe down from the status bar to open the quick access panel and then touch .
2. Touch  **Ethernet**.
3. Slide the switch to the **ON** position.
4. Place the MC3300xR into the Ethernet cradle slot.
5. Touch and hold **eth0** until the menu appears.
6. Touch **Modify Proxy**.
7. Touch the **Proxy** drop-down list and select **Manual**.

Figure 11 Ethernet Proxy Settings

<--> eth0

Proxy
Manual

Proxy hostname
proxy.example.com

Proxy port
8080

Bypass proxy for
example.com,mycomp.test.com,localhost


IP settings
DHCP

CANCEL CONNECT

8. In the **Proxy hostname** field, enter the proxy server address.
9. In the **Proxy port** field, enter the proxy server port number.



NOTE: When entering proxy addresses in the Bypass proxy for field, do not use spaces or carriage returns between addresses.

10. In the **Bypass proxy for** text box, enter addresses for web sites that do not require to go through the proxy server. Use the separator “|” between addresses.
11. Touch **MODIFY**.
12. Touch .

Configuring Ethernet Static IP Address

The MC3300xR includes Ethernet cradle drivers. After inserting the MC3300xR, configure the Ethernet connection:



1. Swipe down from the status bar to open the quick access panel and then touch .
2. Touch  **Ethernet**.
3. Slide the switch to the **ON** position.
4. Place the MC3300xR into the Ethernet cradle slot.
5. Touch **eth0**.
6. Touch **Disconnect**.
7. Touch **eth0**.
8. Touch the IP settings drop-down list and select **Static**.

Figure 12 Static IP Settings

⌂ eth0

Proxy
None ▼

IP settings
Static ▼

IP address
192.168.1.128

Gateway
192.168.1.1

Netmask
255.255.255.0


DNS 1
8.8.8.8

DNS 2
4.4.4.4

CANCEL CONNECT

9. In the **IP** address field, enter the proxy server address.
10. If required, in the **Gateway** field, enter a gateway address for the device.
11. If required, in the **Netmask** field, enter the network mask address
12. If required, in the **DNS** address fields, enter a Domain Name System (DNS) addresses.
13. Touch **CONNECT**.
14. Touch ○.

Establishing Ethernet Connection

1. Swipe down from the status bar to open the quick access panel and then touch .
2. Touch **Ethernet**.
3. Slide the Ethernet switch to the **ON** position.
4. Insert the device into a slot.
The ⌂ icon appears in the Status bar.
5. Touch **eth0** to view Ethernet connection details.

LED Indicators

There are two green LEDs on the side of the cradle. These green LEDs light and blink to indicate the data transfer rate.

Table 7 LED Data Rate Indicators


Data Rate	1000 LED	100/10 LED
1 Gbps	On/Blink	Off
100 Mbps	Off	On/Blink
10 Mbps	Off	On/Blink

4-Slot ShareCradle with 4-Slot Battery Charger

The 4-Slot ShareCradle with 4-Slot Battery Charger:

- Provides 9 VDC power for operating the mobile computer and charging the battery.
- Provides 4.2 VDC power for charging spare batteries.
- Simultaneously charges up to four mobile computers and four spare batteries.
- Compatible with the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries.
 - MC32N0 5200 mAh PowerPrecision extended battery.

Figure 13 4-Slot ShareCradle with 4-Slot Battery Charger Setup



Charging the MC3300xR Battery



NOTE: To function properly, remove the lower part of the rubber boot or the entire rubber boot before placing in a charging cradle.

1. Ensure that the cradle is connected to power.
2. Slide the mobile computer into the slot in the cradle. The mobile computer amber Charge LED Indicator, indicates the mobile computer battery charging status.
3. Gently press down on the device to ensure proper contact.
4. When charging is complete, remove the mobile computer from the cradle slot.

Charging Spare Batteries

Insert the battery into the charger and gently press down on the battery to ensure proper contact.

Battery Charging in the 4-Slot ShareCradle with 4-Slot Battery Charger

The MC3300xR's Charge LED or the spare battery LED indicates the status of the battery charging in the MC3300xR. See [Table 9 on page 40](#) for charging status indications.

The MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries charges from 0% to 90% in less than 3.8 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature

Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.


To accomplish this, for small periods of time, the MC3300xR or cradle alternately enables and disables battery charging to keep the battery at acceptable temperatures. The MC3300xR or cradle indicates when charging is disabled due to abnormal temperatures via its LED.

4-Slot Ethernet ShareCradle with 4-Slot Battery Charger

The 4-Slot Ethernet ShareCradle with 4-Slot Battery Charger:

- Provides 9 VDC power for operating the mobile computer and charging the battery.
- Provides 4.2 VDC power for charging spare batteries.
- Simultaneously charges up to four mobile computers and four spare batteries.
- Compatible with the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries.
 - MC32N0 5200 mAh PowerPrecision extended battery.

Figure 14 4-Slot Ethernet ShareCradle with 4-Slot Battery Charger Setup



Charging the MC3300xR Battery



NOTE: To function properly, remove the lower part of the rubber boot or the entire rubber boot before placing in a charging cradle.

1. Ensure that the cradle is connected to power.
2. Slide the mobile computer into the slot in the cradle. The mobile computer amber Charge LED Indicator, indicates the mobile computer battery charging status.
3. Gently press down on the device to ensure proper contact.
4. When charging is complete, remove the mobile computer from the cradle slot.

Charging Spare Batteries

Insert the battery into the charger and gently press down on the battery to ensure proper contact.

Battery Charging in the 4-Slot Ethernet ShareCradle with 4-Slot Battery Charger

The MC3300xR's Charge LED or the spare battery LED indicates the status of the battery charging in the MC3300xR. See [Table 9 on page 40](#) for charging status indications.

The MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries charges from 0% to 90% in less than 3.8 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature

Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.

To accomplish this, for small periods of time, the MC3300xR or cradle alternately enables and disables battery charging to keep the battery at acceptable temperatures. The MC3300xR or cradle indicates when charging is disabled due to abnormal temperatures via its LED.


Daisy-chaining Ethernet Cradles

Daisy-chain up to ten 5-Slot Ethernet ShareCradle with 4-Slot Battery Chargers to connect several cradles to an Ethernet network. Use either a straight or crossover cable. Daisy-chaining should not be attempted when the main Ethernet connection to the first cradle is 10 Mbps as throughput issues are likely to occur.

To daisy-chain 5-Slot Ethernet ShareCradle with 4-Slot Battery Chargers:

1. Connect power to each 5-Slot Ethernet ShareCradle with 4-Slot Battery Charger.
2. Connect an Ethernet cable to one of the ports on the switch and the other end to the Primary Port of the first cradle.
3. Connect an Ethernet cable to the Secondary port of the first cradle.
4. Connect the other end of the Ethernet cable to the Primary port of the next 5-Slot Ethernet ShareCradle with 4-Slot Battery Charger.

Figure 15 Daisy-chaining 5-Slot Ethernet ShareCradle with 4-Slot Battery Chargers



5. Connect additional cradles as described in step 3 and 4.

Ethernet Settings

The following settings can be configured when using Ethernet communication:

- Proxy Settings
- Static IP.

Configuring Ethernet Proxy Settings

The MC3300xR includes Ethernet cradle drivers. After inserting the MC3300xR, configure the Ethernet connection:



1. Swipe down from the status bar to open the quick access panel and then touch .
2. Touch  **Ethernet**.
3. Slide the switch to the **ON** position.
4. Place the MC3300xR into the Ethernet cradle slot.
5. Touch and hold **eth0** until the menu appears.
6. Touch **Modify Proxy**.
7. Touch the **Proxy** drop-down list and select **Manual**.

Figure 16 Ethernet Proxy Settings

<--> eth0

Proxy
Manual

Proxy hostname
proxy.example.com

Proxy port
8080

Bypass proxy for
example.com,mycomp.test.com,localhost


IP settings
DHCP

CANCEL CONNECT

8. In the **Proxy hostname** field, enter the proxy server address.
9. In the **Proxy port** field, enter the proxy server port number.



NOTE: When entering proxy addresses in the Bypass proxy for field, do not use spaces or carriage returns between addresses.

10. In the **Bypass proxy for** text box, enter addresses for web sites that do not require to go through the proxy server. Use the separator “|” between addresses.
11. Touch **MODIFY**.
12. Touch .

Configuring Ethernet Static IP Address

The MC3300xR includes Ethernet cradle drivers. After inserting the MC3300xR, configure the Ethernet connection:



1. Swipe down from the status bar to open the quick access panel and then touch .
2. Touch  **Ethernet**.
3. Slide the switch to the **ON** position.
4. Place the MC3300xR into the Ethernet cradle slot.
5. Touch **eth0**.
6. Touch **Disconnect**.
7. Touch **eth0**.
8. Touch the IP settings drop-down list and select **Static**.

Figure 17 Static IP Settings

⌂ eth0

Proxy
None ▼

IP settings
Static ▼

IP address
192.168.1.128

Gateway
192.168.1.1

Netmask
255.255.255.0

DNS 1
8.8.8.8

DNS 2
4.4.4.4

CANCEL CONNECT

9. In the **IP** address field, enter the proxy server address.
10. If required, in the **Gateway** field, enter a gateway address for the device.
11. If required, in the **Netmask** field, enter the network mask address
12. If required, in the **DNS** address fields, enter a Domain Name System (DNS) addresses.
13. Touch **CONNECT**.
14. Touch ○.

Establishing Ethernet Connection

1. Swipe down from the status bar to open the quick access panel and then touch ⚙.
2. Touch **Ethernet**.
3. Slide the Ethernet switch to the **ON** position.
4. Insert the device into a slot.
The ⌂ icon appears in the Status bar.
5. Touch **eth0** to view Ethernet connection details.

LED Indicators

There are two green LEDs on the side of the cradle. These green LEDs light and blink to indicate the data transfer rate.

Table 8 LED Data Rate Indicators

Data Rate	1000 LED	100/10 LED
1 Gbps	On/Blink	Off
100 Mbps	Off	On/Blink
10 Mbps	Off	On/Blink

4-Slot Spare Battery Charger


The 4-Slot Battery Charger:

- Charges up to four MC3300xR spare batteries.
- Provides 4.2 VDC power to charge the spare battery.
- Compatible with the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries.
 - MC32N0 5200 mAh PowerPrecision extended battery.

Charging Spare Batteries

1. Connect the charger to a power source.
2. Insert the battery into the charger and gently press down on the battery to ensure proper contact.

Figure 18 4-Slot Battery Charger Setup



Battery Charging

Spare Battery Charging

Each Battery Charging LED indicates the status of the battery charging in each slot. The table below describes the Battery Charging LED status.

Table 9 Battery LED Charging Indicators

LED	Indication
Off	<ul style="list-style-type: none"> The battery is not charging. The battery is not inserted correctly in the cradle or connected to a power source. Cradle is not powered.
Solid Amber	<ul style="list-style-type: none"> Battery is charging.
Solid Green	<ul style="list-style-type: none"> Battery charging is complete.
Fast Blinking Red 2 blinks/second	Charging error, e.g.: <ul style="list-style-type: none"> Temperature is too low or too high. Charging has gone on too long without completion (typically eight hours).
Solid Red	<ul style="list-style-type: none"> Spare battery is charging and battery is at the end of useful life. Charging complete and battery is at the end of useful life.

The MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries charges from 0% to 90% in less than 3.8 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature

Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.

To accomplish this, for small periods of time, the charger alternately enables and disables battery charging to keep the battery at acceptable temperatures. The charger indicates when charging is disabled due to abnormal temperatures via its LED.

20-Slot Spare Battery Charger

The 20-Slot Battery Charger:


- Charges up to twenty MC3300xR spare batteries.
- Provides 4.2 VDC power to charge the spare battery.

- Compatible with the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries.
 - MC32N0 5200 mAh PowerPrecision extended battery.

Charging Spare Batteries

1. Connect the charger to a power source.
2. Insert the battery into the charger and gently press down on the battery to ensure proper contact.

Figure 19 20-Slot Battery Charger Setup



Battery Charging

Spare Battery Charging

Each Battery Charging LED indicates the status of the battery charging in each slot. The table below describes the Battery Charging LED status.

Table 10 20-Slot Battery LED Charging Indicators

LED	Indication
Off	<ul style="list-style-type: none"> • The battery is not charging. • The battery is not inserted correctly in the cradle or connected to a power source. • Cradle is not powered.
Solid Amber	<ul style="list-style-type: none"> • Battery is charging.
Solid Green	<ul style="list-style-type: none"> • Battery charging is complete.

Table 10 20-Slot Battery LED Charging Indicators (Continued)

LED	Indication
Fast Blinking Red 2 blinks/second	Charging error, e.g.: <ul style="list-style-type: none"> • Temperature is too low or too high. • Charging has gone on too long without completion (typically eight hours).
Solid Red	<ul style="list-style-type: none"> • Spare battery is charging and battery is at the end of useful life. • Charging complete and battery is at the end of useful life.

The MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries charges from 0% to 90% in less than 5.5 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature

Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.

To accomplish this, for small periods of time, the charger alternately enables and disables battery charging to keep the battery at acceptable temperatures. The charger indicates when charging is disabled due to abnormal temperatures via its LED.


USB Charge Cable

The USB Charge Cable:

- Provides 5 VDC power to charge the battery.
- Provides power and/or communication with the host computer over USB to the device.
- Compatible with devices using the following batteries:
 - MC3300xR 5200 mAh and 7000 mAh PowerPrecision+ extended batteries.
 - MC32N0 5200 mAh PowerPrecision extended battery.

The USB Charge Cable snaps onto the bottom of the MC3300xR and removes easily when not in use. When attached to the MC3300xR allows charging only.

Figure 20 USB Charge Cable




Connecting the USB Charge Cable to Device



NOTE: To function properly, remove the lower part of the rubber boot or the entire rubber boot before placing in a charging cradle.

To connect the USB Charge Cable to the device, insert the USB Charge Cable straight onto the device until the device touches the bottom of the cable cup.

Figure 21 Connecting the USB Charge Cable




Connecting the USB Charge Cable to Host Computer

To connect the USB Charge Cable to a host computer:

1. Connect the USB Charge Cable to the MC3300xR.
2. Connect the USB connector of the cable to a host computer.

Figure 22 Connecting USB Charge Cable to Host Computer



Main Battery Charging

The device's Charging/Notification LED indicates the status of the battery charging in the device.



NOTE: Charging using a host computer USB port could take longer.


To achieve the best charging results, use only Zebra charging accessories and batteries. Charge batteries at room temperature with the in sleep mode.

Charging the Device

To charge the device using the USB Charge Cable:

1. Connect the USB Charge Cable to the MC3300xR.
2. Connect the USB connector of the power supply.
3. Plug the power supply into a power outlet.

Figure 23 Charging the Device



Main Battery Charging

The device's Charging/Notification LED indicates the status of the battery charging in the device.



NOTE: In many cases, the 90% charge provides plenty of charge for daily use.

To achieve the best charging results, use only Zebra charging accessories and batteries. Charge batteries at room temperature with the MC3300xR in sleep mode.

The MC3300xR 5200 mAh and 7000mAh PowerPrecision+ extended battery charges from 0% to 90% in less than 6 hours at room temperature.


The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 6 hours at room temperature.

Disconnecting the USB Charge Cable

To disconnect the USB Charge Cable from the MC3300xR:

1. Grasp the cable cup in one hand (by pinching the front and back) and the device in the other hand.
2. Remove the device by pulling straight up.

Figure 24 Disconnecting the USB Charge Cable



MC33XX Charge Only Adapter

Use the MC33XX Charge Only Adapter for backwards compatibility with the MC32N0 cradles and the MC3300xR.


- MC33XX Charge Only Adapter supports the MC32N0 1-Slot USB Cradle, MC32N0 4-Slot Charge Only Cradle, and MC32N0 4-Slot Ethernet Cradle.
- MC33XX Charge Only Adapter provides charge only; no communication when used with the MC32N0 cradles.
- MC32N0 1-Slot USB Cradle provides 5.4V DC to charge the device.
- MC32N0 1-Slot USB Cradle (with the MC33XX Charge Only Adapter) is compatible with an MC3300xR Mobile Computer charging either an MC3300xR PowerPrecision+ extended battery or an MC32N0 PowerPrecision extended battery, but the MC32N0 1-Slot USB Cradle spare battery slot is only compatible with the MC32N0 PowerPrecision batteries.

Adapter Installation

To install the MC33XX Charge Only Adapter into the MC32N0 Cradle:


1. Clean the MC32N0 cradle and contacts with an alcohol wipe, using a back and forth motion with your finger. For more information about cleaning, see [Troubleshooting](#).

Figure 25 Clean MC32N0 Cradle




2. Peel and remove the adhesive from the back of the adapter.

Figure 26 Peel and Remove Adhesive




3. Insert the adapter into the MC32N0 cradle and adhere to the bottom of the cradle.

Figure 27 Insert Adapter into Cradle and Adhere



4. Insert the MC3300xR device into the MC32N0 cradle.

Figure 28 Insert MC3300xR device into MC32N0 Cradle



The MC3300xR 5200 mAh and 7000mAh PowerPrecision+ extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Charging Temperature

Charge batteries in temperatures from 0 °C to 40 °C (32 °F to 104 °F). Charging is intelligently controlled by the MC3300xR.

To accomplish this, for small periods of time, the MC3300xR or cradle alternately enables and disables battery charging to keep the battery at acceptable temperatures. The MC3300xR or cradle indicates when charging is disabled due to abnormal temperatures via its LED.

MC3300xR Rubber Boot

The rubber boot provides additional protection for the MC3300xR.




NOTE: To function properly, remove the lower part of the rubber boot or the entire rubber boot before placing in a charging cradle.

If the hand strap is attached, release the hand strap to install the rubber boot. After the rubber boot is installed, reattach the hand strap.

To attach the rubber boot:


1. If the hand strap is attached, remove the hand strap.
2. Slide the battery end of the MC3300xR into the bottom of the rubber boot.

Figure 29 Slide MC3300xR into Bottom of Rubber Boot



3. Grasp the top of the rubber boot and place over the top of the MC3300xR.
4. Re-attach the hand strap (see [Hand Strap on page 54](#)).

Figure 30 Place Rubber Boot Over Top of MC3300xR




Fabric Holster

The Fabric Holster provides a soft holder for the mobile computer. It consists of a fabric mobile computer holder, a detachable shoulder strap and a belt strap. See figures below to attach the Fabric Holster to a belt and shoulder strap.

Belt Strap

Attach the Fabric Holster to a belt or waist band.


Figure 31 Attach the Fabric Holster to a Belt



Shoulder Strap

Attach the fabric holster to a shoulder strap.

Figure 32 Attach Fabric Holster and Shoulder Strap




Using the Belt Strap

The Fabric Holster holds the MC3300xR on a belt or waist band.



1. Secure the Belt Strap over the belt or waistband and snap into place.

Figure 33 Secure Belt Strap On Belt




2. To insert the MC3300xR, slide the mobile computer (battery end first) into the Fabric Holster with the screen facing the user.

Figure 34 Insert MC3300xR



3. Secure the MC3300xR with the restraining strap and place over the MC3300xR to secure in place.

Figure 35 Secure with Strap




4. To remove the MC3300xR, unsnap the restraining strap to release. Lift the MC3300xR out of Fabric Holster.

Using the Shoulder Strap

1. Connect the clips on the shoulder strap to the rings on the fabric holster.
2. Place the shoulder strap over your head and rest on your shoulder.

Figure 36 Shoulder Strap



3. Lift the strap and insert the MC3300xR into the holster.
4. Secure the strap to hold the MC3300xR in place.

Hand Strap

To install the hand strap:


1. Thread the lanyard loop through the opening near the base of the trigger handle.

Figure 37 Insert Loop Through Handle Slot




2. Insert the top end of the hand strap through the loop.

Figure 38 Thread Hand Strap Through Loop



3. Thread the hand strap through the lanyard.
4. Pull the hand strap through the loop.
5. Thread the end of the hand strap with the tab through the slot on the bottom of the MC3300xR.

Figure 39 Thread Tab Through Slot



6. Slide the tab through the slit in the hand strap so that the tip of the tab is facing away from the MC3300xR.

Zebra RFID Mobile Application for Android

The upgraded Zebra RFID Mobile Application is now called the 123RFID Mobile Application. For detailed information about this app refer to the 123RFID Mobile Application User Guide, p/n MN-003765-xx. This guide describes the app for Android and demonstrates the device's capability and tag operation functionality.

The guide is available at: zebra.com/support.

RFID Manager

Introduction

The Zebra RFID Manager application allows the user to perform various management functions on the RFID reader module in the MC3300xR including firmware update, power control for the RFID Radio, resetting the RFID module to factory defaults, and various other functions.



NOTE: Some screens shown in this guide may differ from the actual screens shown on the device. Screens are subject to change with future releases.

Using the RFID Manager for Android

To use this application for RFID operations:

1. Launch the RFID Manager application for Android on the mobile device.
2. During initial use, set the region in which the device is operating. To set the region, open the application and select **Settings > Regulatory**.




NOTE: If the RFID Demo application or partner application is connected to the MC3300xR, the RFID Manager can still perform all management functions, however care should be used as to not interfere with any ongoing operational behavior of the device (e.g., inventory, setting parameters, etc.).

Connection Status

Reader Status

By default, the RFID Reader is powered on and in the **Ready**. If the MC3300xR's RFID Radio is not powered on, the Reader Status displays **Off**.

Figure 40 Reader Connection Status Screens




Client Application Status

If the MC3300xR's RFID Reader Status is **Ready**:

1. Launch the application manually.
2. On the **Home** Screen under **Connection Status > Client Application**, it indicates if the client application is **Connected** or **Disconnected** to the MC3300xR's RFID Reader.

Figure 41 Client Application Status Screens



The **Battery Status** contains the battery **Charging Level** percentage and the **Charging Status** (Charging or Discharging).

RFID Regulatory

To set the region, select the **Regulatory** arrow button to open the **Regulatory** screen. Select the **Region** and **Channel Selection** settings and tap the **Apply** button. The **Region** drop-down displays the current region to which the device is set. Choose the correct region before using the device.





NOTE: The **Region** and **Channel Selection** requires setup before the initial use only. However, if a **Reset to Factory Defaults** operation is conducted on the MC3300xR's RFID Reader, the operation removes the **Region** and **Channel** and needs to be set again.



NOTE: Select only the country in which you are using the device.

- **Channel Selection** is allowed only for the regions that allow channel setting.
- Supported regions are those reported by the specific MC3300xR.
- If the region is not configured on the MC3300xR, the Regulatory status shows as NA.
- A customer application can also set the region and configuration programmatically.

Figure 42 Regulatory Screens



Settings


To display Settings, select the **Settings** icon located on the bottom tool bar.

Turn on the **Settings** slider switch control to enable control of setting options.

Setting options are as follows:


- **Temperature Notification** – If enabled, a temperature high and critical notification appears with temperature level indications.
- **Reader Power Off/On** - If enabled, the MC3300xR's RFID Radio is powered on. When the MC3300xR's RFID radio is powered off, no RFID operations are supported.

Figure 43 Settings Screen




- **Reset to Factory Defaults** - Select **Reset to Factory Defaults** to reset all configuration and region settings to factory default settings. When selected, the RFID reader internally reboots and a window message displays after successful operation.

Figure 44 Reset to Factory Defaults Screen



- **Reset Reader** - Select **Reset Reader** to perform a reader restart. When selected, the reader reboots and a window message displays after successful operation. Reader status confirmation is located under **Home > Status**.

Figure 45 Reader Reset Screen



Firmware Update

A product code update, bootloader, and radio update may be performed using the firmware update screen.



NOTE: More than 15% battery level is required to perform a Firmware Update.

To perform a firmware update:


1. Copy the RFD file into the MC3300xR's SD card. One method is through the abd command (abd push <firmware>/sdcard).



NOTE: The MC3300xR must have USB Debugging enabled in Developer Options for adb commands to work properly.


2. Browse for the firmware RFD file, by clicking on the folder icon.
3. Select the required RFD file, from **File View** menu. When the file is selected, the application returns to update screen.

Figure 46 Transferring Files for Firmware Update




- Click on the **Update** button.

Figure 47 RFID Manage Firmware Update Screen




- Once Update is initiated, a status box displays that the firmware updates is in progress. For more information on the current status of the Firmware update (including a progress bar), refer to the Android Notification bar.
- After a successful update, a window displays a MC3300xR's Firmware Installation Complete message.

Figure 48 Firmware Update Progress Window



The updated firmware information is displayed on the Information screen.

Figure 49 Information Screen



Recovery Mode

Only select the **Recovery Mode** check box (see [Figure 47 on page 65](#)) if the MC3300xR's firmware is suspected to be corrupted. Contact the Zebra support team to use the Recovery Mode option.

RFID Manager Log


The following options may be enabled to capture reader logs.

- **Real-time Logs** - Captures real time logs from the MC3300xR's RFID radio.
- **Retrieve Buffered Logs** - Captures the buffered logs from the MC3300xR's RFID radio.
- **Debug Logs** - Captures RFID System Service debug logs.



NOTE: All three logs can be enabled. If all three logs are disabled, default logs from the application is captured which does not include MC3300xR's RFID System Service logs.

Figure 50 RFID Manager Logger Screen



To capture real time logs:

1. Enable **Real-time logs**.
2. Connect and use the RFID application to create logs.
3. Tap on **Export** to retrieve the real time logs. It is not required to disconnect or exit the RFID application.

The Retrieve Buffered Logs option can only be used if the RFID application is not actively reading or writing RFID tags.

The standard RX Logger application can also be used to get RFIDAPI3 and RFIDSERVICE activity.

Exporting Log Files

To export captured log files, select the **Export** button. The log file is saved as RfidLog.txt at a root of the MC3300xR's SD card file system. Retrieve the log file after connecting with PC through adb. RfidLog.txt file is located in the internal storage of the root folder.

StageNow

Introduction

This chapter provides instruction necessary to generate a RFID Firmware update profile and import RFID CSP plug-in into the StageNow application.


Creating Firmware Update Profile using StageNow

The following provides an example for creating a profile to copy SAADXS00-001-N13.rfd from the staging server to the device and then subsequently updating the firmware.

To create a new update firmware profile:


1. Ensure both the device to be staged and the staging server are connected and accessible through the network.
2. Select **Create New Profile** from the side menu.

Figure 51 Create Firmware Update - CSP Library Screen




3. Select **XpertMode** and tap on **Create** from the **Select a Wizard** window.

Figure 52 Wizard Window Selection




4. Enter a new profile name (For example, Rfid-N13-update as shown in [Figure 90](#)) and tap on **Start**.

Figure 53 Create Firmware Update - Profile Name




- Click on **Add** to add the **FileMgr CSP** and **rfidmanager CSP**.

Figure 54 Create Firmware Update - Add Applications



- Enter the **Target Path** (target path in the device) and the **Source File URL** (select the file path in the stagingserver) as shown in [Figure 92](#) and tap **Continue**.

Figure 55 Create Firmware Update - FileMgr Configurations



7. Select the **UpdateFirmware** action under RFID action list and enter the Target Path and File Name entered previously (/data/tmp/public/SAADX001-N13D0.rfd) and tap **Continue**.

Figure 56 Create Firmware Update - RfidManager Configuration

StageNow

Settings Help About

Current IP : Not Selected | Wi-Fi Hotspot: On | Change Password | Log out

XpertConfig: RFID-N13-Update

Profile Id: 2 Profile Status: Incomplete

StageNow Config Review Publish

1 FileMgr 2 RfidMgr

ADD / EDIT

RfidMgr

Description: Rfid configuration

Create New Setting

☐ Save Setting for Re-use

RFID action

Update Firmware

Firmware Update FileName:

/data/tmp/public/SAADX-001-N13.rfd

Rfid Advanced options

< Back

Continue >

8. Review your input and tap on **Complete Profile**.
9. Select the **Barcode Type** check box required and click on **Test**.

Figure 57 Create Firmware Update - Barcode selection

StageNow

Settings Help About

Current IP : Not Selected | Wi-Fi Hotspot: On | Change Password | Log out

XpertConfig: RFID-N13-Update

Profile Id: 2 Profile Status: Complete

StageNow Config Review Publish

WiFi-Hotspot

You have a Staging Server configured. Would you like to use the new WiFi Hotspot feature instead? This will allow you to create a direct connection to this computer via hotspot. The connection will be secure and remove the need to print the multiples barcodes in the case that you have Device Settings in the Config Section.

☐ Yes, use WiFi Hotspot


Barcode Audio NFC

Type	Staging Client	Last Tested	Published	Latest Staged
PDF417 Recommended for 2D Scan Engines	<input type="checkbox"/> StageNow			
Linear Recommended for 1D Laser Scanner	<input type="checkbox"/> StageNow			
Action	<input type="checkbox"/> Select Select All	<input type="checkbox"/> Test Test	<input type="checkbox"/> Publish Publish	<input type="checkbox"/> Stage Stage

< Back

- The test generates a barcode which can be scanned using the StageNow client on the device to stage the firmware.

Figure 58 Stage Firmware Barcode



Import RFID Manager into StageNow

Introduction

This chapter provides instruction necessary to generate a RFID Firmware update profile and import RFID CSP plug-in into the StageNow application.


Creating Firmware Update Profile using StageNow

In the following provides an example for creating a profile to copy SAADX00-001-N10D0.DAT from the staging server to the device and then subsequently updating the firmware.

To create a new update firmware profile:


1. Ensure both the device to be staged and the staging server are connected and accessible through the network.

Figure 59 Create Firmware Update-CSP Library Screen




2. Select **Create New Profile** from the side menu.
3. Select **XpertMode** and tap on **Create** from the Select a Wizard window.

Figure 60 Wizard Window Selection




4. Enter a new profile name (For example, Rfid-N10-update as shown in [Figure 61](#)) and tap on **Start**.

Figure 61 Create Firmware Update-Profile Name



5. Click on **Add** to add the **FileMgr CSP** and **rfidmanager CSP**.

Figure 62 Create Firmware Update-Add Applications



6. Enter the **Target Path** (target path in the device) and the **Source file URL** (select file path in the staging server) as shown in [Figure 63](#) and click Continue.

Figure 63 Create Firmware Update-FileMgr Configuration

The screenshot shows the StageNow web interface. At the top, there's a navigation bar with 'Settings', 'Help', and 'About'. Below it, a header area displays 'XpertConfig: Rfid-N10-Update' with an edit icon. A progress bar shows three steps: 'StageNow Config' (active), 'Review', and 'Publish'. Below the progress bar, two numbered steps are shown: '1 FileMgr' (active) and '2 rfidmanager'. The main configuration area is titled 'File Action:' and includes three buttons: 'Transfer/Copy File' (selected), 'Delete File', and 'Download and Expand Archive File'. Below this is 'Target Access Method:' with a button 'File in the device file system'. Then 'Target Path and File Name:' with a text input field containing '/data/tmp/public/SAADX00-001-N10D0.DAT'. Next is 'Source Access Method:' with three buttons: 'File on a remote server' (selected), 'File in the device file system', and 'File embedded in XML'. Finally, 'Source File URI:' with a text input field containing 'ftp-p://ftp-dev:M0t04sds@localhost:21/SETTINGS/setting' and a dropdown menu.

StageNow

Settings Help About

XpertConfig: Rfid-N10-Update

StageNow Config Review Publish

1 FileMgr 2 rfidmanager

File Action: ?

Transfer/Copy File Delete File Download and Expand Archive File

Target Access Method: ?

File in the device file system

Target Path and File Name: ?

/data/tmp/public/SAADX00-001-N10D0.DAT

Source Access Method: ?

File on a remote server File in the device file system File embedded in XML

Source File URI: ?

ftp-p://ftp-dev:M0t04sds@localhost:21/SETTINGS/setting

7. Select the **Firmware Update** check-box and enter the **Target Path** and **File Name** entered previously (/data/tmp/public/SAADXS00-001-N10D0.DAT) and tap **Continue**.

Figure 64 Create Firmware Update-RfidManager Configuration

The screenshot shows the StageNow configuration interface. At the top, there's a navigation bar with 'Settings', 'Help', and 'About'. Below it, a header bar shows 'XpertConfig: TEST' with an edit icon. A progress bar indicates three steps: 'StageNow Config' (active), 'Review', and 'Publish'. Below the progress bar, two numbered steps are shown: '1 FileMgr' with a green checkmark and '2 rfidmanager' with an orange pencil icon. The main content area is titled 'rfidmanager' with a 'Configure the Setting' section. Under this section, there's a 'Create New Setting' button. Below that, there's a checkbox for 'Save Setting for Re-use' with a help icon. The 'Firmware Update' checkbox is checked. Below it, the 'Firmware Update FileName:' field is highlighted in yellow and contains the text '/data/tmp/public/SAADXS00-001-N10D0.DAT'. At the bottom, there's a checkbox for 'Rfid Advanced options'.

StageNow

Settings Help About

XpertConfig: TEST

StageNow Config Review Publish

1 FileMgr 2 rfidmanager

SN rfidmanager

Configure the Setting

Create New Setting

☐ Save Setting for Re-use ?

Firmware Update ☒

Firmware Update FileName: ?

/data/tmp/public/SAADXS00-001-N10D0.DAT

Rfid Advanced options ☐

- 8. Review your input and tap on **Complete** Profile.
- 9. Select the **Barcode Type** check box required and click on **Test**.

Figure 65 Create Firmware Update-Barcode selection

StageNow

Settings Help About

Current IP : 10.17.126.35 | Wi-Fi Hotspot: Off | Change

XpertConfig: TEST

Profile Status: Com



StageNow ConfigReviewPublish

Export for MDMExport

WiFi-Hotspot

You have a Staging Server configured. Would you like to use the new WiFi Hotspot feature instead? This will allow you to create a direct connection to this computer via hotspot. The connection will be secure and remove the need to print the multiples barcodes in the case that you have Device Settings in the Config Section.

☐ Yes,use WiFi Hotspot

Barcode		Audio	NFC		
Type		Staging Client	Last Tested	Published	Latest Staged
	PDF417 Recommended for 2D Scan Engines	<input type="checkbox"/> StageNow			
	Linear Recommended	<input type="checkbox"/> StageNow			

< Back

10. Test generates a barcode which can be scanned using the StageNow client on the device to stage the firmware.

Figure 66 Stage Firmware Barcode



StageNow

Profile Name: Rfid-N10-Update


Barcode Type: PDF417

Minimum Compatible MX Version: 6.1

Network Connection: This Profile requires your Zebra device to be able to connect to your StageNow Tool.

Scan Barcodes with StageNow Client:

1



Troubleshooting

Introduction

This chapter provides troubleshooting solutions for potential problems. For more detailed device and accessory troubleshooting, refer to the MC33XX Mobile Computer Integrator Guide at: www.zebra.com/support.

Troubleshooting the MC3300xR

Table 11 Troubleshooting the MC3300xR

Symptom	Possible Cause	Action
RFID Reader does not read tags.	The RF region configuration is not set.	Use the RFID Manager application to set the regulatory region or country operation per the application instructions.
RFID Reader version is not displayed in RFID Manager.	Recovery mode is enabled.	Reboot device.
RFID Reader is responsive but cannot read tags.	Battery is critically low. Reader does not function if battery level is less than or equal to 5%.	Place the RFID reader in the charging cradle until the battery is charged.

Technical Specifications

Introduction

The following sections provide technical specification for the device.

MC3300xR Technical Specifications

The following table summarizes the MC3300xR's intended operating environment and technical hardware specifications.

Table 12 MC3300xR Technical Specifications

Item	Description
Physical Characteristics	
Dimensions	MC3390xR: 6.45 in. L x 3.78 in. W x 10.67 in. D 164 mm L x 96 mm W x 271 mm D MC3330xR: 6.45 in. L x 2.95 in. W x 8.31 in. D 164 mm L x 75 mm W x 211 mm D
Weight (with extended battery)	MC3390xR with SE4750: 743g MC3390xR with SE4850: 768 g MC3330xR with SE4770: 676 g
Display	4.0 inch capacitive; WVGA; color
Imager Window	Corning® Gorilla® Glass
Touch Panel	Corning® Gorilla® Glass touch panel w/air gap
Backlight	LED backlight
Battery	Standard: Rechargeable Lithium-Ion 7000 mAh minimum (3.7V)
Expansion Slot	User accessible microSD slot. Supports up to 32 GB microSDHC.

Specifications

Table 12 MC3300xR Technical Specifications (Continued)

Item	Description
Network Connections	USB 2.0 High Speed (host and client), WLAN and Bluetooth
Notification	Side LEDs and audible tone.
Keypad Options	29-key Numeric 38-key Function Numeric (calculator-style integrated numeric keypad) 47-key Alpha-Numeric (calculator-style integrated numeric keypad)
Voice	PTT Voice Support (Internal Speaker)
Audio	Speaker
Performance Characteristics	
CPU	Qualcomm SD660
Operating System	Android Q
Memory	4 GB RAM/32 GB Flash.
Output Power (USB)	USB: 5 VDC @ 500 mA max.
User Environment	
Operating Temperature	-20°C to 50°C (-4°F to 122°F)
Storage Temperature	-40°C to 70°C (-40°F to 158°F) without battery
Charging Temperature	0°C to 40°C (32°F to 104°F)
Humidity	5% to 95% RH non-condensing
Drop Specification	Multiple 1.5 m (5 ft.) drops to concrete over the entire operating temperature range.
Tumble Specification	1,000 1.6 ft./0.5 m tumbles (hits)
Sealing	IP54
Vibration	5 Hz to 2 KHz
Thermal Shock	-40°C to 70°C (-40°F to 158°F)
Electrostatic Discharge (ESD)	±20 kVdc air discharge, ± 10 kVdc contact discharge
Wireless LAN Data Communications	
Wireless Local Area Network (WLAN) radio	IEEE® 802.11a/b/g/n/ac/d/h/i/k/r/w
Data Rates Supported	2.4 GHz: 144 Mbps 5 GHz: 867 Mbps
Operating Channels	Chan 36 - 165 (5 GHz), Chan 1 - 13 (2.4 GHz); actual operating channels/frequencies depend on regulatory rules and certification agency.

Table 12 MC3300xR Technical Specifications (Continued)

Item	Description
Security and Encryption	Security Modes: WPA and WPA2 (Personal or Enterprise) Encryption: WEP40/WEP104, TKIP and AES Authentication: EAP-TLS; EAP-TTLS (MSCHAP, MSCHAPv2, PAP); PEAP (MSCHAPv2, EAP-GTC); LEAP Other: Wi-Fi certified, and supports IPv6
Certifications	802.11n/ac, WMM-PS, WMM-AC, PMF, Voice Enterprise, Wi-Fi Direct, WPS
Fast Roam	PMKID/OKC/CCKM/802.11r
Wireless PAN Data	
Bluetooth	V4.1, V2.1 + EDR w/ Bluetooth Low Energy (BLE). Class 2
Data Capture	
Scanning	MC3390xR: SE4750-MR 2D, SE4850-ER MC3330xR: SE-4770
RFID	
Standards Supported	EPC Class 1Gen2; EPC Gen2 V2;;ISO-18000-63
RFID Engine	Zebra Proprietary Radio Technology
Fastest Read Rate	900+ tags/sec
Nominal Read Range	MC3390xR: ~60+ ft/~18.2+ m MC3330xR: ~19.7+ ft/~6+ m
RFID Power Output	0 dBm to +30 dBm
RFID Antenna Type	MC3390xR: Integrated Linear Polarized MC3330xR: Integrated Circular Polarized
Frequency Range	865-928 MHz *Specific regional and country settings supported upon country selection
2D Imager Engine (SE4770) Specifications	
Field of View	Horizontal - 48° Vertical - 30°
Image Resolution	1280 horizontal X 800 vertical pixels
Roll	360°
Pitch Angle	+/- 60° from normal
Skew Tolerance	+/- 60° from normal
Ambient Light	Sunlight: 10,000 ft. candles (107,639 lux)
Focal Distance	From front of engine: 17.7 cm (7.0 in.)

Specifications

Table 12 MC3300xR Technical Specifications (Continued)

Item	Description
Laser Aiming Element	Visible Laser Diode (VLD): 655 nm +/- 10 nm Central Dot Optical Power: 0.6 mW (typical) Pattern Angle: 48.0° horizontal, 38.0° vertical
2D Imager Engine (SE4750MR) Specifications	
Field of View	Horizontal - 31.0° Vertical - 23°
Image Resolution	1280 horizontal X 960 vertical pixels
Roll	360°
Pitch Angle	+/- 60° from normal
Skew Tolerance	+/- 60° from normal
Ambient Light	96,900 lux
Focal Distance	From front of engine: 36.0 cm (14.2 in.)
Laser Aiming Element	Visible Laser Diode (VLD): 655 nm +/- 10 nm Central Dot Optical Power: 0.6 mW (typical) Pattern Angle: 48.0° horizontal, 38.0° vertical
Illumination System	LEDs: Warm white LED Pattern Angle: 80° at 505 intensity
2D Extended Range Imager Engine (SE4850) Specifications	
Field of View	Near camera: Horizontal - 32.0°, Vertical 20° Far camera: Horizontal - 12°, Vertical - 7.6°
Image Resolution	1280 horizontal X 800 vertical pixels
Roll	360°
Pitch Angle	+/- 60° from normal
Skew Tolerance	+/- 60° from normal
Ambient Light	Sunlight: 10,000 ft. candles (107,639 lux)
Laser Aiming Element	Laser Wavelength: 655 nm Central Dot Optical Power: 0.6 mW (Class 2 IEC60825:2014)
Illumination System	LEDs: Hyper Red 660nm

Table 12 MC3300xR Technical Specifications (Continued)

Item	Description
Supported Symbologies	
1D	Chinese 2 of 5, Codabar, Code 11, Code 128, Code 39, Code 93, Discrete 2 of 5, EAN-8, EAN-13, GS1 DataBar, GS1 DataBar Expanded, GS1 DataBar Limited, Interleaved 2 of 5, Korean 2 of 5, MSI, TLC 39, Matrix 2 of 5, Trioptic, UPCA, UPCE, UPCE1, Web Code.
2D	Australian Postal, Aztec, Canadian Postal, Composite AB, Composite C, Data Matrix, Dutch Postal, Japan Postal, Maxicode, Micro PDF, Micro QR, PDF, QR Code, UK Postal, US Planet, US Postnet, US4State, US4State FICS.

Index

Numerics

123RFID mobile application	56
1-slot USB charge cradle	22
20-slot spare battery charger	40
4-slot spare battery charger	39
5-slot charge only cradle	25
5-slot cradle with 4-slot battery charger	32
5-slot ethernet cradle	27
5-slot ethernet cradle with 4-slot battery charger	34

A

accessories	18
belt strap	50
fabric holster	50
shoulder strap	51
adapter	
installation	47

B

battery	
4-slot battery charging	33
5-slot battery charging	26
battery comparison	21
battery compatibility	22
charging	23
charging 1-slot	24
spare battery charging	24

C

charge only adapter	47
charging	
5-slot sharecradle	25
compatibility	21
configurations	7
cradles	
daisy-chaining ethernet cradles	35

D

documents	11
-----------	----

E

ethernet	
configure static IP address	30
configuring ethernet	29
establish connection	31

F

features	15, 16
feedback	12

L

label	12
led	
indicators	32

M

manufacturing Label	12
mc3300r	
initial setup	17
technical specifications	81

R

revision history	3
rfid	
antenna	14
components	14
radio module	14
tags	14
technology overview	13
rfid manager	57
client application status	59
connection status	58
exporting log files	67

firmware update	64
recovery mode	66
rfid manager log	67
rfid regulatory	60
settings	61
using rfid manager	57
rfid sled	
troubleshooting	80
rubber boot - MC33XX-G	49

S

sharecradles	
daisy-chaining cradles	28
software	11
stagenow	68
firmware update profile	73

T

troubleshooting	80
-----------------------	----

U

USB charge cable	43
------------------------	----

Z

Zebra RFID mobile application	56
-------------------------------------	----

